

# ZELCO®

## BOOKMARK™ DICTIONARY INSTRUCTIONS

### REMOVE BATTERY RIBBON

- Pull out the protective battery ribbon before turning on the Bookmark Dictionary - BACK VIEW [see ①]

### POWER ON/OFF

- Press the **ⓐ** key to turn the unit ON and OFF [see ②] (Note: unit will shut off automatically after 2 minutes of inactivity)

### DICTIONARY MODE

- Press **ⓑ** key to get into the Dictionary mode [see ③]

### Definition Search

- Within Dictionary mode, type in the word to be searched (Note: you may use all upper case letters)  
For example, "ELECTRICITY" may be typed in, then..
- Press the **ⓓ** key for the definition [see ④]
- Press the **ⓔ** key to view the rest of the definition [see ⑤]
- Press the **ⓕ** key to scroll back to the beginning of the definition [see ⑥]

### Word Search


- Within Dictionary mode, type in a letter or group of letters  
For example, "TY" may be typed in and press the **ⓓ** key to view words starting with "TY"  
For example the definition for "tycoon" will be displayed
- Press the **ⓖ** key to view the previous word/ definition [see ⑦]
- Press the **ⓗ** key to view the next word/ definition [see ⑧]

### Spelling Help


- Within Dictionary mode, press the **ⓙ** key to replace unknown letters in a word to be searched [see ⑨]  
For example, if you don't know how to spell "KINETIC" you may type "KIN?TIC" using the "?" key to replace the "E"  
(Note: the "?" character cannot be used as the first letter)
- Press the **ⓓ** key for the definition [see ④]

### New Word Search

- To start a new search within Dictionary mode you may either press the **ⓓ** key or begin typing a new word [see ⑩]



FRONT VIEW



BACK VIEW

**CLOCK SETTING**

- Press the **C** key [see (11)]
- Press **A** key to toggle between 12 Hour and 24 Hour formats [see (12)]
- Press the **ENTER** key to enter the time setting mode [see (13)]
- Use the number keys to set time (use 24 Hour format - for example 8:32 pm will be entered as 08:32 in 12 Hour format or 20:32 in 24 Hour format)
- Press **ENTER** key to confirm time setting [see (4)] and the cursor will automatically switch to date setting
- Use the number keys to set date (year/month/day)
- Press the **ENTER** key to confirm the date setting [see (4)]

**DAILY ALARM SETTING**

- Press **C** key to toggle to Daily Alarm mode [see (14)] - be sure "A" icon is visible in LCD display (Note: there are only two alarm modes to toggle between, Daily and Schedule)
- With Daily mode on - press **ENTER** key to enter the alarm setting mode [see (13)]
- Refer to [Clock Setting] for entering and setting time
- Press the **DEL** key to activate the alarm [see (10)] "A" icon will appear to indicate the alarm is set

**SCHEDULE ALARM SETTING**

- Press **C** key to toggle to Schedule Alarm mode [see (14)] - be sure the "S" icon is visible in the LCD display
- With Schedule mode on - press **ENTER** key to enter the alarm setting mode [see (13)]
- Refer to [Clock Setting] for entering and setting date
- Press **ENTER** key to enter time setting mode [see (4)]
- Refer to [Clock Setting] for entering and setting time
- Press **ENTER** key to enter message mode [see (4)]
- Enter a 58 character maximum message per event alarm (Note: you may enter up to 32 maximum event alarms)
- Press **ENTER** key to save the message [see (4)] (Note: events saved in Schedule Alarm mode will automatically alarm until deleted - there is no need to activate the alarm)

**SCHEDULE ALARM SETTING continued...**

- Within Alarm mode, to view previously saved events press the **F** key [see (11)]
- You may also press the **A** key to scroll previously viewed saved events [see (11)]
- To delete a saved event, view the event in Schedule Alarm mode and press the **DEL** key [see (10)]

**LOWER CASE LETTERS**

- To type lower case letters, press the **SHIFT** key once to activate the cursor [see (15)] (Notice: the cursor will change from a blinking underscore to a full blinking block)
- type the character for the lowercase letter
- Reactivate the **SHIFT** key for every lowercase instance [see (15)] (Note: numbers cannot be typed into messages) For example the number "2" must be spelled out - "two"

**CALCULATOR MODE**

- Press **MODE** key to get into the Calculator mode [see (16)]
- Enter the number(s) you wish to calculate
- Press a function key in the arrow cluster [see keys (5) through (8)]
- Additional function keys can be found on the keypad
- Enter second number(s)
- Press **ENTER** key to perform calculation [see (4)]

**RESETTING** - in case product malfunctions

- Use a paper clip or pin to press reset button - BACK VIEW [see (17)] (Note: all Scheduled Alarms and Messages will be erased)